





INSTALLATION GUIDE









You Will Need:







Hammer Tape Measure

Shears

Be Safe:




- Always assess the job before any work at height is carried out
- Ensure all equipment is checked, is suitable and in good repair.
- 3. Ensure adequate fall restraints and protection is used.
- 4. Always wear safety clothing on site.

1 Check that the Tiles are Genuine

Look on the back of the tile for the production code and the Decra logo



2 Battens




Batten Space

Α


330mm 370mm


3 Lay the Tiles



Tiles to be laid from the ridge down in order; 1, 2, 3, 4 and 5.













9 Wall Flashing



- 1 Tile
- 2. Tile Batten
- 3. Ventilation Space Batten
- 4. Decra Foil
- 5. Rafter
- 6. Ventilation Space
- 7. Side Flashing
- 8. Rende
- 9. Warmth Insulation
- 10. Purpose-Made Side Flashing
- 11. Sealant



Cutting and Bending the Tile

- 1. Measure and mark the required measurements taken from the roof on the tiles with chalk, ensuring that the matching corrugation of the overlapping tile ready to be cut is taken as the measurement starting point. This forms the bending line.
- 2. Flatten both upstands of the tile where it is to be cut. This will make the cutting easier.
- 3. Cut the tile along the marked cutting line using the hand shears.
- 4. Bend the tile using a short tile bender.









Helpline:



0816 79 10 251







